

DATASHEET

Issue 1.0



Multifunction Meters

Transducers & Isolators

Temperature Controllers

Converters & Recorders

Digital Panel Meters

Current Transformers

Analogue Panel Meters

Shunts

Digital Multimeters

Clamp Meters

Insulation Testers

POWER FACTOR METERS LF 72 / LF 96

ANALOGUE METERS





Application

The moving coil indicators and a phase angle adjuster are used to monitor changing power factor conditions on ir-reversible balanced load systems.

The power factor is indirectly determined by measuring the phase angle ϕ between current and voltage (both sinusoidal). However the indicators are calibrated in values of cosine of the angle ϕ . These meters offer several advantages in Switchboard & Generating Set panels. Number of meters can be mounted in Panel Cut out (Mosaic Mounting). The Bezel, glass and dial can be easily replaced.

Features

- Knife edge pointer
- Glass filled polycarbonate housing
- Easily replicable glass and bezel

Applicable Standards

| Nominal case and cutout dimensions for | IS 2419 | |
|--|-------------------------|--|
| indicating electrical instruments | DIN IEC 61554 | |
| Scale and pointer for electrical | IS 1248 | |
| measuring instruments | DIN 43802 | |
| Connections & terminal markings for | IS 1248 | |
| panel meters | DIN 43807 | |
| Terminal bolts / leads | DIN 46200/46282 | |
| Clamp straps for connections | DIN 46282 | |
| Safety requirements and protective | IS 9249 | |
| measures for Electrical indicating | DIN 40050 | |
| instruments and their acessories | VDE 0110 | |
| | VDE 0410 | |
| | IEC 529,IEC 1010 | |
| Performance specifications for direct | IS 1248 | |
| acting indicating analogue electrical | IEC 51/DIN EN 60051 | |
| measuring instruments and their | DIN 43701 | |
| accessories | | |
| Front frames for indicating measuring | DIN 43718 | |
| instruments principle dimensions | | |
| Technical conditions of delivery for | DIN 43701 | |
| electrical instruments | | |
| UL Combustibility class | UL 94 V-0 | |
| Mechanical strength | IS 1248, IEC 51 IS 9000 | |
| (Free fall test, vibration test) | VDE 041 | |
| | IEC 61010 | |
| L | 1 | |

Comply with following European directives:

 $2004\,/\,108\,/\,EC$ (EMC directive), $2006/95\,/EC$ (low voltage directive) & amendment 93/68/EEC, For Marking.

Scale and Pointer

| Pointer | Knife - edge pointer | |
|-----------------------|---------------------------|--|
| Pointer deflection | 0° 90° | |
| Scale characteristics | Non - Linear | |
| Scale division | Coarse-fine | |
| Scale length | Lf72 Lf96 | |
| | 61mm 97mm | |
| Interchangeability | Scales are interchangeble | |

Mechanical Data

| Case details | Moulded square case suitable for mounting in Control / Switchgear panels, Machinery consoles |
|-----------------|--|
| Case material | Polycarbonate, flame retardant and drip proof as per UL 94 V-0 |
| Front facia | Glass |
| Colour of bezel | Black |
| Position of use | Vertical |
| Panel fixing | Mounting Clamps |
| Mounting | Stackable in a single cutout |
| Panel thickness | < 25 mm |
| Terminals | Hexagon studs, M4 screws and wire clamps E3 |

Electrical Data

| Measured quantity | Power Factor | |
|---|--|--|
| Overload capacity (acc to IS: 1248/ IEC 51/ DIN EN 60051) | | |
| Continuously Short duration | 1.2 times rated current | |
| Current circuit | 10 times rated current for 0.5 sec, 9 overloads 10 times rated current for 5 Sec, 1 overload | |
| Voltage circuit | 2 times rated current for for 0.5 sec, 9 overloads 2 times rated current for 5 Sec, 1 overload | |
| Power consumption(Approx |):- | |
| Current path | < 1.0 VA | |
| Voltage path | < 3.0 VA | |
| Enclosures code (IEC 529) | IP 52 case | |
| Insulation class | IP 00 for terminals without backcover | |
| Rated insulation voltage | Group A according to VDE 0110 660 V | |
| Proof voltage testing | 2 KV | |
| Installation catagory (IEC 1010) | 300 VCAT III | |
| Insulation resistance | > 50 Mohm at 500 V d.c. | |



Accuracy at Reference Conditions

| | 1.5 according to IS:1248 (IEC 51/ DIN EN 60051) |
|--|--|
|--|--|

Reference conditions

| Ambient temperature | 23 0C ± 2 0C |
|---------------------|--|
| Position of use | Nominal position ± 10 |
| Waveform | Sinewave |
| Distortion Factor | < 1 % |
| Current | 95100 % rated current |
| Warmup | ³ 5 minutes at min 80% of rated |
| | current and 100 % of rated voltage |
| Voltage | Rated voltage + 2% |
| Frequency | 50 Hz +/ - 0.1% |
| Other Conditions | as per |
| | IS: 1248 (IEC 51/ DIN EN 60051) |

Nominal range of use

| Ambient temperature | 050°C |
|-------------------------|---------------------------------------|
| Position of use | Nominal position + 50 |
| External magnetic field | At 0.4KA/m |
| Voltage | Rated voltage + 15% |
| Current | 20 to 120 % of rated current |
| Frequency | 49-51 Hz |
| | for single phase 45-65 Hz for 3 phase |

Environmental Conditions

| Climatic suitability | Climate category II as per IS: 1248 |
|-----------------------|--------------------------------------|
| | (climatic class 3 according to |
| | VDE / VDI 3540) |
| Operating temperature | -10 + 55 °C |
| Storage temperature | -25 + 65 °C |
| Relative humidity | < 75% annual average, non-condensing |
| Shock resistance | 15gn for pulse duration 11 ms |
| Vibration resistance | 10-55-10Hz for ampli. 0.15mm |
| | (1.5 g at 50Hz) |
| Pollution degree | 2 |

Options

| Case | |
|-----------------------|------------------------------------|
| Front facia | Antiglare glass |
| Colour of bezel | Red, Yellow, Blue, White |
| Red index pointer | Front adjustable on site |
| Position of use | on request 00 1800 |
| Dial | |
| Blank dial | With initial and end values marked |
| Special markings | Numbering/Lettering |
| Division dials | Basic divisions without numbering |
| Colour markings/bands | Red or green |

Standard Measuring Ranges

Types

E - Single Phase System

D - Three Phase System Balanced Load

Measuring Ranges

COS φ cap 0.5...1...0.5 ind COS φ cap 0.8...1...0.3 ind COS φ cap 0.8...1...0.8 ind

Rated Voltage

Following single phase and three phase voltages are available as standard. The voltages will be considered as a phase voltage(between phase & Neutral) in case of single phase meters and as a line voltage (between two phases) in case of 3 phase 3 wire or 4 wire meters.

Please specify the application (single ph. & 3 ph. 3 wire or 4 wire)

Rated Current 1A 5A

Non-Standard ranges available on request.

Accessories


Safety terminal protection

Full sized polycarbonate back cover to provide protection against accidental contact (hand and fingers). (acc. to IS 9249 VDE 0410)

Functional Principle

The measuring system comprises a moving coil indicator & phase angle converter attached to the case of indicating instrument. moving coil movements has pivots of very high hardness movement is suspended. between spring loaded saphire jewels. movement is properly shielded & critically damped by eddy currents induced in coil former.

Schematic Diagram








A current transformer 1 of the phase angle converter provides input current to the electronic circuit. Both the input voltage and the current are passed to a bistable filp-flop stage 2.


The pulse duty cycle of flip-flop is proportional to the phase angle .A low pass filter allows the mean value which is proportional to the phase angle and is fed to the moving coil movement 3.

Connections


LF 72/96 Single phase



LF 72/96 three phase three wire balanced load



Dimensions





| Front in mm | Nominal Dime | ensions, mm | Cutout, mm | Installation Depth | Installation Depth |
|-------------|---------------------------------|-------------|---------------------------------------|----------------------------|-------------------------------|
| | a ₁ x a ₂ | h | $I_1 \times I_2$ | Including Terminal (t), mm | Incl. Full back Cover (f), mm |
| 72 x 72 | 72 x 72 | 5.5 | 68 ^{0.8} x 68 ^{0.8} | 82.5 | - |
| 96 x 96 | 96 x 96 | 5.5 | 92 ^{0.8} x 92 ^{0.8} | 54 | 62.5 |

Safety Precautions

- 1) Instruments with damaged bezel or glasses must be disconnected from the mains.
- 2) Adequate safety clearance must be maintained to control panel fasteners and to sheet metal housing. If non insulated connector wires are used.
- 3) The back cover must be snapped into place after connector wires have been clamped for protection against accidental contact.
- 4) Bezel, Scale and Glassmay only be replaced undervoltage free conditions.
- 5) Instrumentstobeusedingroundedpanel.

Ordering Information

| Туре | |
|---------------------|--|
| LF | Power Factor meter |
| Front Dimension | |
| 72 | 72mm x 72mm |
| 96 | 96mm x 96mm |
| Measuring Ranges | Refer to table inside |
| Terminal Protection | Full sized polycarbonate back cover |
| Rated voltages | Refer to table inside |
| Rated currents | 1A, 5A |
| Front facia | Normal glass*1 |
| | Antiglare glass*3 |
| | Polycarbonate glass*3 |
| Colour of Bezel | Black*1 |
| | Red, Blue, Yellow, White*3 |
| Position of use | Vertical*1 |
| | on request 01800*3 |
| Dial | Standard scale same as measuring range*1 |
| | Blank dial with division*3 |
| | Additional lettering on request*3 |
| | Additional numbering on request*3 |
| | Coloured marking red or green*3 |
| | Coloured sector red or green*3 |

^{*1} Standard

Ordering example

LF 96 for 3 phase 4 wire system balanced load, measuring range ($\cos\phi$) cap 0.5...1...0.5 ind, rated voltage AC 230V, rated current 1A.

Specifications are subject to change without notice (07/09)

^{*3} Please clearly add the desired specifications while ordering



Contact



01376 335271

E-mail: sales@sifamtinsley.com

Tel:

1 Warner Drive Springwood Industrial Estate Braintree, Essex CM7 2YW

www.sifamtinsley.co.uk